



## SCISSOR MOTORCYCLE LIFT JACK

### MANUAL EN



## 1. Using the lift


The scissor lift is supplied assembled in ready-to-use state. Optional adapters are separately packed and if needed can be inserted onto the lift according to the provided image. Slide them into the desired position and secure their location by tightening the wing nuts on the adapter's side. You can adjust the adapter's height and orientation by screwing it up and down.

The lift height can be raised or lowered by turning the hexagon marked on the image. You can use the included key or a 22mm socket wrench for this. After extending the lift to the desired height, always insert the safety bar and secure it with the pins.

The lifting height is 90-510mm, and the maximum weight capacity of the scissor lift is 500kg. To assure optimal stability, use the lift at the center of gravity of the motorcycle.

For safe and easy repeated use of the lift, for example, in workshops, you can permanently fix it to the floor using the anchor holes with a size of 30x10mm in the lower part of the lift.

For further information, visit the product page on our eshop at [sefismoto.com](http://sefismoto.com)



## 2. Warning

Do not exceed the maximum weight capacity. Follow basic safety rules during use of the lift. Do not insert fingers or objects into the scissor mechanism of the lift. High risk of injury. Do not use in the presence of children.