




1. Using the paddock stand

Out of package the paddock stand is in folded position. To fold and unfold the paddock stand arms loosen the **hand screw** on side of the arm, move the arm and then tighten it again.


The paddock stand allows option to lock-in the rear pair of wheel with the **step-on brake**.



2. Adapter installation

To install or adjust the adapter unscrew the **adapter locking bolt** and insert the adapter. The depth of the adapter can be adjusted to fit width of specific motorcycle.

Place the paddock stand with adapters in line with the motorcycle swing arm or front forks to measure and adjust the adapters properly and then fix their position by tightening **adapter locking bolt** by hand.



3. Warning

When using two paddock stands always lift rear wheel first and then proceed to lift the front wheel. It is advised to not lift motorcycle alone as the safest use is for one person to hold the motorcycle while another person lifts it using the paddock stand. Prior to the use always inspect technical condition of the paddock stand and the adapter set up. Keep away from children when in use. Maximum carrying capacity of single paddock stand is **200 kg** for maximum motorcycle weight of **400 kg**.